

ONE·TOUCH™

www.ONETOUCHPRODUCTS.com

AUTOMATIC RECHARGEABLE CAN OPENER



USER MANUAL

Model no.: KC14

CAUTION

- Read all instructions carefully before using your Rechargeable Can Opener.
- Close supervision is necessary when your Rechargeable Can Opener is used by or near children.
- **DO NOT** open pressurized (aerosol-type) cans.
- **DO NOT** open cans of flammable liquids such as lighter fluids.
- Not suitable for rimless cans or cans with odd corners.
- Make sure the motor has stopped completely before taking off the bottom cover for cutter cleaning.
- During cutter cleaning **DO NOT** press the switches on the bottom and the button on the top of your Rechargeable Can Opener to avoid turning the unit on.
- Avoid contact with moving parts. Keep hands, hair, jewelry, clothing etc away from moving parts during operation to prevent injury, and/or damage to the Rechargeable Can Opener.
- To maintain your Rechargeable Can Opener at its optimal condition, **DO NOT** immerse it in water or any other liquids.
- **DO NOT** try to adjust or remove the cutter screw.
- **NOT** suitable for dish washer.


SAVE THESE INSTRUCTIONS

This Rechargeable Can Opener is intended for household use only.

Read the following instructions before using for the first time.

Parts and Functions

fig.1




Getting Started

BATTERY CHARGING

Your Rechargeable Can Opener is powered with a rechargeable battery pack. To charge the Rechargeable Can Opener, plug in the connector to the DC Jack (see fig.2). Then plug the other end into an AC mains power socket. It takes about 7 hours to fully recharge the battery. You can then disconnect the charger.

For first charging, it is recommended to charge overnight.

fig.2




USING THE "ONE TOUCH" RECHARGEABLE CAN OPENER

1. Place your Rechargeable Can Opener on top of the can with its rim positioned in the groove at the bottom of the Rechargeable Can Opener (see fig.3).


NOTE: The cutter will not operate unless it is positioned correctly on the rim of the can.

To open the cans with tab, turn them upside-down, so that the Rechargeable Can Opener can work on the lid without tab.





2. With the can on a flat surface, press the Start button for about one second and release it once the Rechargeable Can Opener starts to cut the can (see fig.4). After cutting, the Rechargeable Can Opener will stop automatically. (see fig.5)

NOTE: The maximum can size that can be fully cut in one go is 98mm (3.85") diameter. If the lid of a bigger can, needs to be completely removed, move the unit back 10mm and press the Start Button again and let go once it resumes cutting. Once again, the Rechargeable Can Opener will stop automatically after cutting.



3. When the cutting has completed, lift the Rechargeable Can Opener off the can. A magnet on the Rechargeable Can Opener will pick up the lid as well for convenience (see fig.6).

NOTE: There is functional sharp edge on the round cutter, and should be treated with care.




Care and Maintenance


1. If the Rechargeable Can Opener slows during cutting, this may indicate low battery level and the battery should be recharged. If the Rechargeable Can Opener stops during operation, see "Trouble Shooting" below.
2. To clean the cutter, first slide off the bottom cover and remove the battery as a safety precaution. Wipe the cutter with a damp cloth or a sponge, using a mild non-abrasive cleaner, followed with a clean, dry cloth to dry it completely.

Trouble Shooting

1. If the Rechargeable Can Opener is jammed due to low battery level or a deformed can rim, press the small button at the rear of the Rechargeable Can Opener to activate the reverse so that the can is released, keep the Reverse Switch depressed until the Rechargeable Can Opener stops (see fig.7).



2. If the battery is depleted the Rechargeable Can Opener may not be released by pressing the Reverse Switch. In this case, insert a 4 or 5 mm Crosshead (or flat) screwdriver into the Stall Release Screw, and slowly turn it in a anti-clockwise direction as viewed underneath (as arrow) until the can is released (see fig.8).



NOTE: After recharging the battery following use of the Stall Release Switch, press and hold the Reverse Switch and Can Detect Switch (see fig.1) together until the Rechargeable Can Opener resets to its start position. Keep your fingers away from the Cutter and Drive Wheel to prevent injury.

NOTE: Always allow for a full charge cycle (7 hours) before re-using the Can Opener after a jam caused by a low battery or depleted battery.

3. Cans with heavy seams, odd shapes, or uneven rims may stall the Rechargeable Can Opener. If this happens, follow above procedure to release the can. Start the cutting action just beyond any minor bump or dent in a can.

NOTE: The Rechargeable Can Opener will not open rimless cans or cans with odd corners.

Technical Specifications

Operate voltage: DC2.4V

Battery: Rechargeable battery

Maximum can cutting size in one cycle: diameter 98mm (3.85") (preferred)

FCC STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning : Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user authority to operate the equipment.

NOTE : This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.